

# Corrosion Under Insulation

## Understanding Issues Surrounding Corrosion Under Insulation

**Peter Bock**

Senior Corrosion Control Specialist

Chicago Corrosion Group

Skokie, IL/Houston, TX

[peterbcui@gmail.com](mailto:peterbcui@gmail.com)

713-396-6383

# Corrosion Under Insulation

**CUI is a recent branch of corrosion control  
Developed in the 1980s and early 1990s  
Primarily in Petrochemical and Refining  
Response to ban of lead, chromium, asbestos  
Changes in piping, vessel, and tank design  
Development of better CUI coatings**

Summarized from  
Three-day  
NACE New Orleans Section  
CUI Mitigation Course



# Corrosion Under Insulation



**What's  
Really  
Under  
There?**

# Corrosion Under Insulation



## The Challenge:

**A typical major refinery or chemical plant may contain a thousand insulated vessels and tanks and a thousand miles of insulated or coated and wrapped pipe.**

**Current corrosion condition (CUI), inspection intervals, scheduled maintenance, and record keeping may vary widely.**

**Current maintenance budgeting is rarely enough to keep up with corrosion failures, much less to get ahead.**

**Current specifications and new construction practices do not always provide long-term assurance.**

# Corrosion Under Insulation



## The Reality:

**Jacketed and Insulated Equipment in a well-run refinery or chemical plant with an active RBI (Risk Based Inspection) program is inspected once every 3 years or less often, based on the severity rating of the vessel or pipe run.**

**The 3-year inspection is typically 99% (area) exterior visual and about 1% full removal and observation of the substrate.**

**CUI Coatings, insulation, and jacketing are typically replaced on an 8-15 year cycle for liquid applied coatings and on a 15 to 30 year cycle for TSA in CUI service.**





This is how  
Insulated and Jacketed  
Equipment  
Should Always Look

# Corrosion Under Insulation



And this is what we see in real life.



# Corrosion Under Insulation



**Major perforations  
caused by CUI**





# Corrosion Under Insulation

## The CUI System


**Like a good sandwich,  
All the parts of a CUI System  
Must be compatible and effective**



- (1.) Red—Stored or Carried Product**
- (2.) White—Product-Compatible Lining**
- (3.) Black—Vessel or Pipe wall**
- (4.) Gray—CUI Coating**
- (5.) Yellow—Insulation**
- (6.) Gray—External jacketing**


# Corrosion Under Insulation

## The CUI Cycle (1.)



# Corrosion Under Insulation

## The CUI Cycle (2.)




During rain, dew, or fog  
or whenever water is present

**when the stored/carried  
product temperature is low**  
and rain, dew, or fog occur, or  
water from some other source  
is on the outside of the  
jacketing, over extended time  
periods (years),  
water may penetrate the  
jacketing, displace air in the  
insulation, and may eventually  
reach the substrate.

# Corrosion Under Insulation

## The CUI Cycle (3.)




**When carried/stored product temperature rises, it heats the vessel or pipe wall and water trapped in the insulation boils, steams away from the hot steel, and travels through the insulation toward the jacketing, where it condenses, but is still trapped beneath the jacketing.**



# Corrosion Under Insulation

## The CUI Cycle (4.)




**When the temperature is lower again, water in the insulation migrates back toward the substrate and corrosion can occur if there is not a good corrosion-resistant CUI coating.**

# The CUI Cycle

Typically 8 to 10 years before Repair/Replacement


Water gets under jacketing



Most water cannot escape


Water accumulates under jacketing

Substrate stays wet  
Eventually causing corrosion



# Corrosion Under Insulation

## The CUI Cycle (5.)




# Corrosion Under Insulation

## Industry Standards



<  
**API RP 583**  
**First Edition**  
**May 2014**

>  
**NACE SP0198-2010**  
**June 2010**  
**Originally Issued**  
**February 1998**



**Both Documents stress a “systems” approach**



# Corrosion Under Insulation

## 2.1.3 Relevant guidelines & standards for the industrial/mechanical insulation industry in North America

In North America there are no regulations or codes governing the design and installation of industrial/mechanical insulation. Best practices is generally adopted following a variety of different standards & guidelines published by bodies such as ASTM, NACE, MICA & PIP.

Many ownership groups in North America have developed their own internal standards and guidelines which are used throughout various projects. The intention of the PIP guidelines is to consolidate these internal standards from ownership groups to create a uniform approach.

The commonly referred to standards and guidelines in North America include:

- ASTM C1696
- NACE SP0198
- MICA National Commercial & Industrial Insulation Standards

**Before Publication  
of API RP 583**

# Corrosion Under Insulation

API 583 defines 3 generic types of insulation most commonly used in oil refineries and petrochemical plants:

**Granular**

**Fibrous**

**Cellular**

Major Generic types of Insulation listed in NACE SP 0198-2010,

<u>NACE SP 0198 Listing</u>	<u>Type</u>	<u>ASTM</u>
Par. 5.2.1 Pg. 27	Calcium Silicate	ASTM C533
Par. 5.2.2 Pg. 27	Expanded Perlite	ASTM C510
Par. 5.2.3 Pg. 28	Mineral Fiber/Wool	Various ASTM
Par. 5.2.4 Pg. 28	Cellular Glass	ASTM C552
Par. 5.2.5 Pg. 28-29	Organic Foams	Various ASTM
Not Listed	Aerogel Blanket	
Not Listed	Spray-On Acrylic	
Not Listed	Epoxy Syntactic Foam	

# INSULATION

## API RP583 chart of insulation types:

Table 6 Commonly Used Insulation Materials

Insulation Material	Low Temperature Range		High Temperature Range	
	°F	°C	°F	°C
Granular Calcium silicate	0	-18	1200	650
Granular Expanded perlite			600	315
Cellular Cellular glass	-450	-260	900	480
Fibrous Mineral wool	32	0	1800	1000
Fibrous Fiberglass	-20	-30	1000	540
Cellular Polyurethane	-350	-210	250	120
Cellular Polyisocyanate foam	-290	-180	300	150
Cellular Elastomeric foam	-70	-55	250	120
Cellular Polystyrene foam	-60	-50	165	75
Cellular Phenolic foam			300	150
Aerogel Silica Aerogel	-460	-270	1200	650

# CALCIUM SILICATE (Granular)

**Quoted direct from API RP 583:**

## **Advantages:**

**Low thermal conductivity**

**Usable to 1000°F (538°C) cont./1200°F (650°C) intm.**

**Available in a variety of shapes/sizes/thicknesses**

## **Disadvantages:**

**Can absorb and retain water**

**Has pH of 9-10 when exposed to water**

**Care needed to avoid breakage during installation**



# EXPANDED PERLITE (Granular)

**Quoted direct from API RP 583:**

## **Advantages:**

**Water resistant up to 400°F (205°C)**

**Good resistance to mechanical damage**

**Available in a variety of shapes/sizes up to NPS 24**

## **Disadvantages:**

**More fragile than calcium silicate during installation**

**Higher thermal conductivity than calcium silicate**

# CELLULAR GLASS (cellular)

**Quoted direct from API RP 583:**

## **Advantages:**

**Does not absorb water**

**High resistance to mechanical damage when jacketed**

**Thermal conductivity does not deteriorate with aging**

## **Disadvantages**

**Fragile as glass**

**Thermal shock at temp. gradient  $>300^{\circ}\text{F}$  ( $>150^{\circ}\text{C}$ )**

**Abrades in vibrating service, fragile before application**

**(Not from API RP 583)**

**Low permeability and absorption make cellular glass an ideal system for cold and cryogenic service.**

# MINERAL WOOL (fibrous)

**Quoted direct from API RP 583:**

## **Advantages:**

**Used in hot applications up to 1200°F (650°C)**

**Lower conductivity than calcium silicate and perlite**

**Low leachable chloride content (< 5ppm)**

## **Disadvantages:**

**Readily permeable to vapors and liquids.**

**Subject to mechanical damage**

**Low compressive strength and lack of resiliency**

# MINERAL WOOL (fibrous)

**Not from API RP 583:**

**Most widely used insulation type in Petro CUI (and elsewhere)**

**Available from multiple manufacturers/vendors**

**Quality and performance may vary by manufacturer and grade**

**Binder used can affect performance characteristics**

**“Water Resistant” grades are available**

**Specifiers don’t always specify required level of quality**

**Contractors buy the cheapest generic equal**

# MINERAL WOOL

## DONE WRONG AT AN ASIAN PLASTICS PLANT





# SILICA AEROGEL BATTS

**Quoted direct from API RP 583:**

Silica Aerogel is synthetically produced amorphous silica gel, distinctly different from crystalline silica. Aerogel is impregnated into a non-woven flexible fabric substrate (batts or blankets) for reinforcement.



# AEROGEL INSULATION BATTS

**Quoted direct from API RP 583:**


## **Advantages**

- Highest thermal performance of any insulating material known**
- Significantly reduced thickness for equivalent performance**
- Wide range of temperature applications**

## **Disadvantages**

- Aerogels are typically hygroscopic (absorb water from air)**
- Need chemical treatment to be hydrophobic**
- Typically higher material cost**  
**(easier installation/better performance justify extra cost)**

# Corrosion Under Insulation



**Crushed jacketing =  
Crushed Insulation =  
Water ingress =  
Wet Insulation =  
Loss of Efficiency**

# Corrosion Under Insulation

## Wet Insulation

### Wet Insulation

(Regardless of what kind


or what original, dry k value)

Doesn't Insulate.

Wet insulation is also a primary cause of CUI.

# Wet Insulation

Magnitude and Rate of Uptake When Submerged in 5" of Water



Possibly Biased Sales Presentation Information



# Corrosion Under Insulation

## CUI Coatings

**API RP 583 Makes no CUI Coating Recommendations**  
**Refers all coatings decisions to NACE SP-0198-2010**

**NACE SP-0198-2010 rates CUI coatings**  
**(1.) By Temperature Tolerance**  
**(2.) By use on Stainless and/or Carbon Steel**

**CUI mitigation has emphasized “better” CUI coatings**  
**rather than preventing water ingress and wet insulation.**

# Corrosion Under Insulation

## Wet Insulation

- A primary cause of corrosion under insulation is water ingress through the jacketing, into the insulation and to the substrate.



## THE ENEMY\*

\*Note that we used Club Soda, which contains chemicals, just like the water that gets under jacketing.

# Corrosion Under Insulation

## NACE SP 0198-2010 Recommended CUI Coating Systems

High Build Epoxy (SS) (CS)	-50 to 140° F
Fusion Bond Epoxy (CS)	-50 to 140° F
Phenolic Epoxy (SS) (CS)	-50 to 300° F
Novolac Epoxy (SS) (CS)	-50 to 400° F
Silicone Hybrid (CS)	-50 to 400° F
Thin Film Silicone (SS)	-50 to 1000° F
Polysiloxane Hybrid (SS) (CS)	-50 to 1200° F
Thermal Spray Aluminum (SS) (CS)	-50 to 1100° F
Aluminum Foil Wrap (SS)	-50 to 1000° F
Wax Tape Wrap (CS)	140° F Maximum

# Corrosion Under Insulation

## Typical Application Times for Liquid Applied Coatings:

<b>1<sup>st</sup> Coat:</b>	<b>apply</b>	<b>1 hour</b>
	<b>drying time</b>	<b>8-12 hours</b>
	<b>inspection</b>	<b>1 hour</b>

<b>2<sup>nd</sup> Coat:</b>	<b>apply</b>	<b>1 hour</b>
	<b>drying time</b>	<b>8-12 hours</b>
	<b>inspection</b>	<b>1 hour</b>

<b>Spot repair low film thickness (if needed)</b>		
	<b>apply</b>	<b>1 hour</b>
	<b>drying time</b>	<b>8-12 hours</b>
	<b>inspection</b>	<b>1 hour</b>

**Total: 3 days**

# Corrosion Under Insulation

TSA video goes here



# Corrosion Under Insulation



The corrosion engineer for the tower on the right estimated every day out of service cost the owner \$1,000,000 in lost production.

# Corrosion Under Insulation Jacketing

Both API RP 583 and NACE SP0198-2010 spend a lot of space discussing jacketing, specifically aluminum or stainless steel sheet metal jacketing.

API RP 583 gives new construction structural design recommendations to minimize water ingress.

NACE SP0198-2010 includes numerous diagrams of metal jacketing where water ingress is expected.

Both documents assume water ingress is **inevitable**.

# Corrosion Under Insulation Jacketing



Count the seams in the Metal Jacketing.

After 8 to 12 years service with no  
maintenance and inspection every 3 years

there will be numerous gaps and leaks

# Corrosion Under Insulation

## Nonmetallic Jacketing



**Jacketing doesn't need to be shiny (or metal) to be good.**



# Corrosion Under Insulation

**NACE SP 0198-201 and API RP 583 both assume metal (Aluminum or Stainless Steel) Jacketing as “standard”  
Some overseas facilities use 2 sides galvanized jacketing.**

**Sheet Metal jacketing is pieced together from hundreds (thousands?) of pieces of sheet metal with joints between each piece.**

**Joints are supposed to be caulked and leakproof.  
Sheet metal jacketing is assumed to be damage resistant.**





# Corrosion Under Insulation

## Nonmetallic Jacketing

### FRP (Fiberglass Reinforced Plastic) Jacketing:

Supplied as a preformed sheet in boxed 1 m x 10 m rolls

Sandwiched between two non-adhesive plastic sheets

Cut and installed at jobsite

Self-curing (sunlight or UV light)

No heat or catalyst is used


Self-adhesive at laps and joints

Forms a monolithic jacket

Cures to 1.5 – 2.0 mm thickness

No caulking of joints required

Can be double-layered at areas of expected damage



# Corrosion Under Insulation

## Nonmetallic Jacketing

### Product properties

	Performance	Standard
Color	Grey	-
Handling / Application temperature	min. 5°C - max. 45°C	-
Service temperature	max. 90°C	-
Emissions (styrene)	< 20 ppm (MAC-value 25 ppm), safety data sheet upon request	-
Flashpoint (non-cured)	125°C	-
Reaction to fire	C <sub>L</sub> -s1, d0 round C-s2, d0 flat	EN 13501-1
	Surface burning characteristics; Flame spread = passed. Smoke development=passed	ASTM E84
Density	1.8 g/cm <sup>3</sup>	ISO 1183
Thickness (after curing)	1.5mm - 2.0 mm	-
Linear expansion coefficient	25*10 <sup>-6</sup> K <sup>-1</sup>	ISO 11359-2
Hardness	45 Barcol	ASTM D2583
Tensile strength	50 MPa	EN ISO 527-4 *
Tensile modulus	9 GPa	EN ISO 527-4
Tensile elongation at break	1.0%	EN ISO 527-4
Compressive strength	150 MPa	EN ISO 14126
Water vapour permeability	0.001 g/m <sup>2</sup> .h.mmHg	ASTM E96
Chemical resistance	available upon request	-
Compliance	ProRox GRP 1000 conforms to CINI 3.2.11 "Weather resistant UV-curing fiberglass reinforced polyester (GRP)" *	-

# Corrosion Under Insulation

## INSPECTIONS AND SERVICE LIFE

Major Oil, Chemical, and Petrochemical Company coating system specifications currently Rate CUI Liquid Applied Coating Systems as **8 to 15** years Service Life.

The same companies' specs rate CUI Thermal Spray Aluminum as high as **30** years Service Life.

Several specs require no intermediate inspections for CUI Thermal Spray Aluminum.

Can you trust anything for 30 years  
without looking at it occasionally?

# Corrosion Under Insulation Risk-Based Inspection Program

**Hazard—Something that has potential to cause harm**


**Risk—Likelihood of a specified undesired event occurring within a specified time period or resulting from specified circumstances**

**Safety Critical Elements—What needs to be protected**

**Mitigation—Measures to prevent the hazard occurring**

**ALARP—As Low As Reasonably Practicable**

# Corrosion Under Insulation



# Corrosion Under Insulation Risk-Based Inspection Program

**Plant Survey to evaluate relative risk of units or sections**  
**Units or sections are assigned severity levels**  
**Rating is by management and operators**

**Regular spot inspections are scheduled**  
**Inspected points are highest-risk units or sections**  
**If problems are found, additional inspection is done**  
**Lower risk areas are surveyed based on**  
**condition of high-risk units or sections**

**Maintenance funding is allocated based on inspection**  
**Maintenance is scheduled to lower event risk**  
**(High risk units with problems receive priority)**  
**Inspection frequency is adjusted based on findings**




# Corrosion Under Insulation

## Risk-Based Inspection Program



**Typical Properly Done RBI Inspection Spot.**  
Spots are designated for Severity  
Annual Inspection Rotates Severest Spots  
Each spot is visualized every 3 to 5 years  
Or more often if unexpected corrosion is found.

# Corrosion Under Insulation Risk-Based Inspection Program



**This is a  
Good Basic Primer  
on  
Risk Based Inspection**

**JPCL Magazine  
August 2013  
Available online**

# Corrosion Under Insulation

Questions?



**Peter Bock**

Senior Corrosion Control Specialist  
Chicago Corrosion Group  
Skokie, IL/Houston, TX  
peterbcui@gmail.com  
713-396-6383

# Corrosion Under Insulation

All photos and illustrations

Copyright © 2016, Peter Bock

Except::

Slide 6      Courtesy RTI

Slide 35     Courtesy Turner Industries

Slide 38     Courtesy RTI

Slide 45     Courtesy Shell EP Americas

Slide 47     Courtesy International Paint Company

Slide 48     Courtesy JPCL Magazine

(Used with permission)

## Peter Bock

Senior Corrosion Control Specialist

Chicago Corrosion Group

Skokie, IL/Houston, TX

[peterbcui@gmail.com](mailto:peterbcui@gmail.com)

713-396-6383